







Print out of the box

▲ DOWNLOAD ADAPTER









Print

Download and print the small adapter on your 3D printer. The adapter has a opening for a piece of a kitchen sponge to clean the filament.

Place

Place the adapter through the hexagon shaped cutout on the side of the box. Press firmly to secure the adapter by snapping it in place.

Guide

Direct the filament through the adapter. Pay attention to the correct guiding to enable a smooth unwinding of the filament.

Done

Place the box upside down so the filament goes straight upwards and load the filament into your 3D printer as usual